

ER-RC1101 - Refractory Bricks Assembly

ER-RC1105 - Side Refractory Brick (x1)

ER-RC1102 - Back Refractory Brick (x1)

ER-RC1103 Bottom Refractory Brick (x1)

ER-RC1104 - Front Refractory Brick (x1)

ER-RC1111 - Bottom Firebox Insulation




ER-RD0903 - Left Glass Assembly

ER-RD0901 - Complete Door Assembly

ER-RD0902 - Right Glass Assembly

ER-RD1203 Spark Guard

ER-RC1201 - Bottom Standoffs (pair)




LINEAR 50 SP

Date: 2017-11-22

Revision: 00

Page: 1 of 3



LINEAR 50 SP

Date: 2017-11-22

Revision: 00


Page: 2 of 3

ER-RD0505
Outside Air Control Door Spring



ER-RD0506
Outside Air Control Cable Spring


ER-RC0503
Damper Chain Hook




ER-RC0504
Damper Chain




ER-RD0501
Outside Air Control (with cable)




ER-RD0201
Baffle



ER-RD0202
Baffle Rail (1)




ER-RC1204
Rectangular Intake Grill



ER-RC1207
Insulated Flex with Outlet Adapter

ER-RC1206
Rectangular Outlet Adapter

ER-RC1205
Rectangular Outlet Grill



LINEAR 50 SP

Date: 2017-11-22

Revision: 00

Page: 3 of 3